



SLIDE SWITCH CLASSIC

- Will fit all Laserlyte® round body lasers
- Switch provides constant on for user
- Button can be activated from both sides



SLIDE SWITCH CLASSIC

To turn "On" the laser, press either side of the switch inward until it clicks.

To turn "Off" press the switch back to the centered position.



www.laserlyte.com

RoHS

